

ARCS PROCEDURE	DISDROMETER MAINTENANCE TEST	PRO(DISD)-001.000
Author: M. J. Bartholomew		14 February 2006 Page 1 of 1

Disdrometer Maintenance Test

I. Purpose:

This document outlines procedure for Disdrometer weekly preventative maintenance test.

II. Cautions and Hazards:

- Keep sensor free of any debris.

III. Requirements:

- None.

IV. Procedure:

A. Testing Disdrometer

1. Push TEST button.
2. LED #4 on processor from panel should light, and sensor should produce a faint 1000 Hz sound.
3. If LED #4 does not light or a different LED lights, processor may not be connected properly. Check sensor cable connections, and repeat test.

V. References:

1. None.

VI. Attachments:

1. None.